

PRODUCTS CATALOGUE

"AT EASE IN YOUR CONSTRUCTION SITE"

www.ritmo.it





Ritmo meets all your welding needs in your jobsite



The information and photos in this publication are not binding and RITMO S.P.A. is free to make any alterations without prior notice.

A DVANTAGE

RITMO



RITMO WORLDWIDE

Ritmo has professional distributors and resellers all over the world. Our staff is ready to assist you in English, Spanish, French, German, Arab, Italian, Russian and Portuguese.

TRAINING

From many years now, we have decided that the best way to grant a client/distributor a perfect knowledge of our products is to invest in custom training, in our own premises. These courses are aimed to teach how to operate the products in the best way, and how to supply the "first aid" when necessary.

PRESALES TECHNICAL ASSISTANCE

When a client or a potential client wants to buy us a product, it is our standard procedure to help find the best solution to its needs.

GLOBAL ADVICE

In such a technical field as ours, the customer requires the best assistance. Thanks to the experience developed along the years, and to the co-operation with several manufacturers, institutions, schools and training institutes, RITMO is able to give the most comprehensive advice to no matter which related issue. Our company is a long-time member of a UNIPLAST's (UNI-Italian National Plastics Standards Body) working group dedicated to the study and draw up of new standards within our field. The importance of this group is linked to the fact that the expansion of the plastic welding field ought to be followed by a crescent sensitivity for safety issues, so to have a sustainable and continuous growth. The working group prepares draws, hence present them to the UNI to be discussed and eventually transformed into new standards.


AFTER SALES TECHNICAL ASSISTANCE

Ritmo's Service Centre can solve all kind of technical issues, as well as overhaul our machines. Ritmo has other Service Centres abroad, linked to its official distributors.

STARTING AND TESTING

RITMO' technicians are prepared to make the starting and testing of workshop machines at the client' own premises, so that the fittings production can start almost immediately.

SOCKET WELDERS



MANUAL EQUIPMENT	WORKING RANGE Ø mm	16	20	25	32	40	50	63	75	90	110	125
	R 25	16	20	25								
	R 63	16	20	25	32	40	50	63				
	R 125 Q	16	20	25	32	40	50	63	75	90	110	125
	WORKING RANGE Ø mm	16	20	25	32	40	50	63	75	90	110	125

SOCKET FUSION MACHINE	WORKING RANGE Ø mm	20	25	32	40	50	63	75	90	110	125
	PRISMA JIG	20	25	32	40	50	63				
							63	75	90	110	125
	PRISMA 125 LIGHT	20	25	32	40	50	63				
							63	75	90	110	125
	PRISMA 125		25	32	40	50	63	75	90	110	125
WORKING RANGE Ø mm	20	25	32	40	50	63	75	90	110	125	

 ON REQUEST

SADDLE SOCKET FUSION MACHINE	WORKING RANGE Ø mm	
	PRISMA UP 90	MAIN PIPE 63 ÷ 250 mm SADDLE FITTING 20 ÷ 90 mm
	FM 630-125	MAIN PIPE 50 ÷ 630 mm SADDLE FITTING 20 ÷ 125 mm



PRISMA JIG

The PRISMA JIG is a compact socket welding machine for HDPE, PP and PP-R, PVDF, PB OD 20* ÷ 125 mm (standard composition steel clamps from Ø 63 to 125 mm; on request clamps from Ø 20 to 63 mm). The machine displays a steel frame that can be used as a support to the aligning body; the unit distinguishes itself by being able to work in tight spaces, after a swift releasing manoeuvre of the frame.

The PRISMA JIG has two trolleys, a fixed and a movable one, with practical closing handwheels in order to ensure a perfect grip in between clamp and pipe/fitting. The machine also features steel auto-centering clamps: a special clamp for the fitting, and a couple of paired clamps designed to keep the pipe in position. The trolley closing and opening operations are performed by a “mutual” starter. The special fittings clamp is placed on the fixed trolley. Whenever the type of work requires a different clamping configuration, it is rather easy to unlock and change the machine’s operativeness.

The heating operation is performed by the R 125 Q hand socket welder with TFE fixed temperature control. The main distinctiveness of the TFE device is its security: an acoustic auto-diagnosis alarm indicates when the heating plate has reached the working temperature, but also shuts off the heating plate automatically if any anomaly happens. Thanks to a combined control system, the TFE device responds rather quickly to any temperature fluctuation forced by external causes; on the other hand, it also gives a greater stability, welding precision and reliability in time. A sustaining handle may be placed at the heating plate, in order to simplify the working phases.

The R 125 Q is available in 110 and 230 V. The welding machine is available in two versions, depending on the type of sockets & spigots supplied: Type A and Type B.

STANDARD COMPOSITION

- Machine body complete with clamps and frame
- R 125 Q TFE hand socket welder
- Socket welder fork support
- Clamps for OD 63-75-90-110-125 mm (A or B type) sockets & spigots
- Transport case for socket welder and sockets & spigots
- Transport case for machine body
- Sustaining handle and tool kit



TECHNICAL FEATURES

PLUS

**CLAMPS
20 ÷ 63mm
(on request)**

**WORK
IN TIGHT SPACES**



Working range	63 ÷ 125 mm standard 20 ÷ 63 mm clamps on request
Materials	HDPE, PP, PP-R, PB, PVDF
Power supply	110 V Single Phase 50/60 Hz 230 V Single Phase 50/60 Hz
Total absorbed power	1400 W
Working temperature	260° (± 10° C) 500° F (± 50° F)
Outside temperature range	-5° ÷ 40° C (23° ÷ 104° F)
Dimensions machine body	400 x 337 x 267 mm 15.7" x 13.3" x 10.5"
Dimensions machine body and frame	400 x 337 x 382 mm 15.7" x 13.3" x 15"
Socket welder	175 x 50 x 395 mm 6.9" x 2" x 15.5"
Transport case Prisma Jig	390 x 350 x 500 mm 15.3" x 13.8" x 19.7"
Transport case Socket welder	490 x 310 x 485 mm
Weight machine body	9,55 Kg (21 lb)
Weight frame Prisma Jig	2,5 Kg (5.5 lb)
Weight Socket welder	3,16 Kg (6,8 lb)





**Ritmo**
PLASTIC WELDING TECHNOLOGY



The information and photos in this publication are not binding and RITMO S.P.A. is free to make any alterations without prior notice.



RITMO S.p.A.
Via A. Volta, 35/37 - 35037
Bresseo di Teolo (PADOVA) ITALY

Ph. +39 049 9901888
Fax +39 049 9901993

info@ritmo.it
www.ritmo.it

